



KK 100 - Stains

We are convinced that, if handled properly, no stains will occur even on delicate fabrics.

If you have problems with staining, then please pay special attention to the following:

- * keep a distance of 25-30 cm
 - * spray sparingly and not on the fabric to be embroidered, but on the backing, e.g. on embroidery backing
1. If stains have been caused by incorrect handling, it is best to contact a dry cleaner with the following information:

Material	Adhesive:	vinyl acetate polymer
Composition:	Solvent: :	methylal
	Propellant gas (aerosol):	dimethyl ether

Solubility: in ketones (acetone), ethyl acetate, chlorinated solvents (trichloroethylene, perchloroethylene), aromatic hydrocarbons (benzene, toluene)

Not soluble in aliphatic hydrocarbons (petrol) and alcohol

2. Of course you can also try to remove the stain yourself. We recommend to get one of the listed solvents in a drugstore or pharmacy.

- * Place felt underneath stain
- * Soak a piece of fabric (preferably of the same kind as the embroidered fabric) in denatured alcohol and rub stain.

Should there be any rings as a result from stain removal, rub rings again with soaked piece of fabric and dry **fast**, using an iron. But do **not place** iron **directly onto** fabric. Use it only as a heat source, 1 cm above the fabric..